

MOUNTING SUGGESTIONS:

BMW R nineT 2014-2015 Solo and Passenger Seat

Hardware:	Solo seat:	Passenger seat:
	Stock Torx bolts and washers	1⁄4″-20 x 1-3⁄4″ hex bolt
	Mounting bracket	¼"zinc washer
	Tube of synthetic grease	¹ ⁄2" plastic spacer
Tools needed:	T-30 Torx wrench	
	⁷ / ₁₆ " nutdriver	

Removal of Stock Seat:

1. Remove the Torx bolt and washer from under the fender below the passenger seat using a T-30 Torx bit.

2. Lift passenger seat up and back to disengage from the fender.



3. Release latch at the rear of the stock solo, and lift back and up to remove from the frame.

4. Remove the two Torx bolts and washers holding the handstrap to the frame and set aside. This hardware will be used to mount your Mustang solo.

5. Remove the handstrap and seat mounting bracket from the frame.



Installation of Mustang Seat:

1. Install the supplied mounting bracket to the frame with the stock Torx bolts and washers.

2. Open the tube of synthetic grease and squeeze a small amount into the rubber grommet on the bracket.



3. Engage the front brackets of the Mustang solo under the frame mounts, and then pivot the seat down toward the frame.

4. Align the nipple on the back of the solo with the mounting bracket and push down to pressure-fit them together. Check to be sure the solo seat is secure to the mounting bracket before riding the motorcycle.

If the front of the seat is not tight in the front mount, the motorcycle's front mounting bracket can be adjusted by loosening the two Torx screws with a T-30 bit and repositioning the bracket. Re-tighten the Torx screws securely before mounting. 5. To install the passenger seat, slide it forward so the seat bracket engages the fender bracket. Position the plastic spacer between the seat and the fender. Place the supplied zinc washer onto $\frac{1}{4}$ "-20 x 1- $\frac{3}{4}$ " hex bolt, and push it up under and through the fender, through the plastic spacer, and thread it into the rear passenger seat mount. Secure with a $\frac{7}{16}$ " nutdriver.



6. The solo can also be used with the stock aluminum cowl. Installation is identical to the passenger seat, except use the stock hardware rather than the $\frac{1}{4}$ "-20 x 1- $\frac{3}{4}$ " bolt.



Enjoy the comfort and custom look of your new Mustang seat!



These steps are guidelines to help you install your new Mustang product. If you need further assistance, please call us at 800-243-1392 or 413-668-1100, Monday through Friday 9:00 - 5:30 Eastern or send an e-mail to questions@mustangseats.com or visit our website at www.mustangseats.com.

For care and maintenance of our seats, please go to our website under "Support".

Refers to part numbers: 76847, 76848

